

Part number Fitting



Description Fitting #6,#8,#10,#12 O STRAIGHT

Part number Fitting



Description Fitting #6,#8,#10,#12 O 90°

Part number Fitting



Description Fitting 1/2 #8 O 90° Valve Seat

Part number Fitting



Description Fitting 5/8 #10 O 180° Valve Seat

Part number Fitting



Description Fitting 5/8 #10 O 90° Valve Seat

Part number Fitting



Description ALuminum Male Fitting #6,#8,#10,#12 STRAIGHT

Part number Fitting



Description Ferrule Steel #6,#8,#10,#12

Part number Fitting



Description Ferrule Aluminium #6,#8,#10,#12

Part number Fitting




Description Y Fitting Male 3/8 #6,#8

Part number Fitting




Description T-Fitting Male 3/8 #6,#8

Part number Fitting



Description SWIVEL Fitting #6, #8, #10 O STRAIGHT

Part number Fitting



Description MALE NUT ALI- #6, #8, #10

Part number Fitting



Description FITTING #6, #8, #10 O 45*

Part number Fitting



Description STEEL FITTING #6, #8, #10 O STRAIGHT

Part number Fitting



Description STEEL FITTING #6,, #8, #10 O 90*

Part number Fitting



Description STEEL FITTING #6, #8, #10 O 45*

Part number Fitting



Description Fitting 3/8 #6 O 90° Valve Seat

Part number Fitting



Description Fitting 1/2 #8 180° Valve Seat..

Part number Fitting



Description **WELD ON BARB #6, #8, #10**

Part number Fitting



Description **O ON BARB #6, #8, #10 (INTERNAL)**

Part number Fitting



Description **SPLICER ALUMINUM #6, #8, #10**

Part number Fitting



Description **SPLICER STEEL #6, #8, #10**

Part number Fitting



Description **Exp/Valve Fitting #6, #8, #10 O 90°**

Part number Fitting



Description **Splicer Aluminum #6, #8, #10 W R134 Valve Seat**

Part number Fitting



Description **FITTING T PIECE #6, #8, #10**

Part number **FI-UN-070-01**

Description **Fitting 3/8 #6, #10 FLAIR STRAIGHT**